
WASHING MACHINE 洗衣機 MESIN BASUH **เครื่องซักผ้า** MÁY GIĂT

INSTRUCTION BOOKLET 説 明 手 冊 BUKU PETUNJUK ดูมือการใช้งาน HƯỚNG DẪN SỬ DỤNG



EW 859 F











Dear customer,

Please read these operating instructions carefully and pay particular attention to the safety notes indicated in the first pages. We recommend that you keep this instruction booklet for future reference and pass it on to any future owners.

Transport damages

When unpacking the appliance, check that it is not damaged. If in doubt, do not use it and contact the Service Centre.

The symbols you will see on some paragraphs of this booklet have the following meaning:



The warning triangle and/or the key words (Warning!, Caution!) emphasize information that is particularly important for your safety or correct functioning of the appliance.



The information marked with this symbol provides additional instructions and practical tips on the use of the appliance.



Tips and information about economical and ecological use of the machine are marked with this symbol.

Our contribution to the protection of the environment: we use environmentally friendly paper.

Contents

	Laundry weights	.9
	Removing stains	.9
	Detergents and additives	.10
	Quantity of detergent to be used	10
•	Washing programmes11-	12
•	Operating sequence13-	14
•	International wash code symbols	.14
M	aintenance	.15
•	Bodywork	15
•	Detergent dispenser drawer	15
•	Water inlet filter	.15
•	Drain filter	.15
•	Emergency emptying out	.15
S	omething not working16-	17

Marnings

The following warnings are provided in the interests of overall safety. You must read them carefully before installing or using the appliance.

Installation

- All internal packing must be removed before using the appliance. Serious damage may be caused to the machine or adjacent furniture if the protective transit devices are not removed or are not completely removed. Refer to the relevant paragraph in the instruction book.
- Any electrical work required to install this appliance must be carried out by a qualified electrician.
- Any plumbing work required to install this appliance must be carried out by a qualified plumber.
- After having installed the machine, check that it is not standing on its electrical supply cable.
- If the appliance is placed on a carpeted floor, ensure that air can circulate freely between the feet and the floor.

Use

- This appliance is designed for domestic use. It must not be used for purposes other than those for which it was designed.
- Only wash fabrics which are designed to be machine washed. Follow the instructions on each garment label.
- Do not overload the appliance. Follow the instructions in the instruction book.
- Make sure that all pockets are empty. Objects such as coins, safety pins, pins and screws can cause extensive damage.
- Do not machine wash garments saturated with petroleum, methylated spirits, trichlorethylene, etc.
 If such fluids have been used to remove stains prior to washing, wait until they have completely evaporated from the fabric before placing garments in the appliance.
- Place small items such as socks, belts, etc. in a cloth bag or pillowcase to prevent them getting trapped between the drum and the tub.
- Use only the recommended quantities of fabric softener. An excessive amount could damage the laundry.
- Leave the porthole door slightly ajar when the appliance is not in use. This preserves the door seal and prevents the formation of musty smells.
- Always check that water has emptied out before opening the door. If not, drain the water following the instructions in the instruction book.

 Always unplug the appliance and shut the water tap after use.

General safety

- Repairs to the machine must be carried out only by qualified personnel. Repairs carried out by inexperienced persons could cause serious danger. Contact your local Service Centre.
- Never pull the power supply cable to remove the plug from the socket; always take hold of the plug itself.
- During high temperature wash programmes the door glass may get hot. Do not touch it!

Child safety

- Children are often not aware of how dangerous electrical appliances can be. When the machine is working, children should be carefully supervised and not be allowed to play with the appliance.
- The packaging components (e.g. plastic film, polystyrene) can be dangerous to children - danger of suffocation! Keep them out of children's reach.
- Keep all detergents in a safe place out of children's reach.
- Make sure that children or pets do not climb into the drum.
- When the appliance is to be scrapped, cut off the electrical supply cable and destroy the plug with the remaining cable. Disable the door catch in order to prevent children from becoming trapped inside while playing.



Packaging materials

The materials marked with the symbol \triangle are recyclable.

- >PE<=polyethylene
- >PS<=polystyrene
- >PP<=polypropylene

This means that they can be recycled by disposing of them properly in appropriate collection containers.

Machine

Use authorised disposal sites for your old appliance. Help to keep your country tidy!



Tips for environmental protection

To save water, energy and to help protect the environment, we recommend that you follow these tips:

- Normally soiled laundry may be washed without prewashing in order to save detergent, water and time (the environment is protected too!).
- The machine works more economically if it is fully loaded.
- With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- Measure out detergent according to the water hardness, the degree of soiling and the quantity of laundry being washed.
- Select "Quick wash" for lightly soiled laundry.

Technical specifications


DIMENSIONS	Height Width Depth	85 cm 60 cm 58 cm	
POWER SUPPLY VOLTAGE/FRE TOTAL POWER ABSORBED MINIMUM FUSE PROTECTION	220-230V/50 Hz 2200 W 10 A		
WATER PRESSURE	Minimum Maximum	50 kPa 800 kPa	
MAXIMUM LOAD	Cottons, linens Synthetics, delicate fabrics Woollens	5 kg 2 kg 1 kg	
SPIN SPEED		800 rpm	



 $m{\xi}$ This appliance complies with the following EEC Directives: 73/23/EEC of 19/02/73 relating to low voltage 89/336/EEC of 03/05/89 relating to electromagnetic compatibility

Description of the appliance

- 1 Detergent dispenser drawer
- 2 Programme chart
- 3 Control panel
- 4 Door handle
- 5 Drain filter
- 6 Adjustable feet



Installation

Unpacking




All transit bolts and packing must be removed before using the appliance.


You are advised to keep all transit devices so that they can be refitted if the machine ever has to be transported again.

 Using a spanner, unscrew and remove the rear right-hand bolt and lay the machine on its back, taking care not to squash the hoses. This can be avoided by placing one of the corner packing pieces between the machine and the floor.




- 2. Remove the polystyrene blocks from the underside of the machine and release the two plastic bags.
- 3. Carefully remove the right-hand bag (1) then the left-hand bag (2) by pulling them towards the centre of the machine.
- 4. Unscrew and remove the feet.






 Fit the grid (A) on the bottom of the machine using the four screws (B) you will find in the bag containing the instruction booklet.
 Re-fit the feet.



- 6. Set the machine upright and remove the two remaining bolts from the back.
- 7. Pull out the three plastic spacers from the holes into which the bolts were fitted.
- 8. Plug the open holes with the plugs which you will find in the envelope containing the instruction booklet.






Positioning

Install the machine on a flat hard floor.

Make sure that air circulation around the machine is not impeded by carpets, rugs etc. Check that the machine does not touch the wall or other kitchen

Carefully level by screwing the adjustable feet in or out. Never place cardboard, wood or similar materials under the machine to compensate for any unevenness in the floor.





Water inlet

Connect the water inlet hose supplied with the machine to a tap with a 3/4" thread.

Do not use already employed inlet hoses.

The other end of the inlet hose which connects to the machine can be turned in any direction. Simply loosen the fitting, rotate the hose and retighten the fitting, making sure there are no water leaks.






The inlet hose must not be lengthened. If it is too short and you do not wish to move the tap, you will have to purchase a new, longer hose specially designed for this type of use.

Water drainage

The end of the drain hose can be positioned in three ways:

Hooked over the edge of a sink using the plastic hose guide supplied with the machine. In this case, make sure the end cannot come unhooked when the machine is emptying.

This could be done by tying it to the tap with a piece of string or attaching it to the wall.




In a sink drain pipe branch. This branch must be above the trap so that the bend is at least 60 cm above the ground.

Directly into a drain pipe at a height of not less than 60 cm and not more than 90 cm.

The end of the drain hose must always be **ventilated**, i.e. the inside diameter of the drain pipe must be larger than the outside diameter of the drain hose.

The drain hose must not be kinked. Run it along the floor; only the part near the drainage point must be raised.



Electrical connection (Only for Hong Kong and Malaysia)

This machine is designed to operate on a 220-230 V, single-phase, 50 Hz supply.

Check that your domestic electrical installation can take the maximum load required (2.2 kW), also taking into account any other appliances in use.

WARNING: THIS APPLIANCE MUST BE

EARTHED.




The manufacturer declines any liability should this safety measure not be observed.

The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS1363A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow - Earth
Blue - Neutral
Brown - Live



The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol $\frac{1}{=}$ or coloured green and yellow.

The wire coloured blue must be connected to the terminal «N» or coloured black.

The wire coloured brown must be connected to the terminal marked «L» or coloured red.

Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.

A

WARNING:

A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard.

Ensure that the cut off plug is disposed of safely.

Please ensure that when the appliance is installed the power supply cable is easily accessible.

Electrical connection

This machine is designed to operate on a 220-230 V, single-phase, 50 Hz supply.

Check that your domestic electrical installation can take the maximum load required (2.2 kW), also taking into account any other appliances in use.

Connect the machine to an earthed socket.




The manufacturer declines any responsibility for damage or injury through failure to comply with the above safety precaution.

Should the appliance power supply cable need to be replaced, this should be carried out by our Service Centre.


Please ensure that when the appliance is installed the power supply cable is easily accessible.

Use

Control panel



1 Detergent dispenser drawer and programme chart



There is a programme guide in English in the handle of the detergent dispenser drawer.

The programme guides in the other languages are supplied with the instruction booklet.

2 Spin speed reduction button ↓6

By depressing this button the spin speed is reduced as follows:

- cottons & linens: from 800 rpm to 400 rpm
- synthetics, delicates, wool: from 750 rpm to 400 rpm

3 Half load button (1/2)

Select this button to reduce water consumption on the rinse cycle when washing a half load of cottons or linens.

The machine will carry out 2 rinses instead of 3 on programmes 1-2-3 and 3 rinses instead of 4 on programme 4.

4 Anti-crease (water in the tub) button

By depressing this button on programmes 7-8-9-10-11 and 12 the water of the last rinse is not emptied out to prevent the fabrics from creasing.

To drain the water and gently spin the laundry, depress this button again.

To drain water only, select programme 14.

5 ON/OFF button (1)

By depressing this button the machine starts operating. When depressing it again, the machine stops.

6 Operating pilot light

This light is on whilst the machine is operating and goes out at the end of the programme.

7 Temperature selector dial



Turn this dial to select the washing temperature. Position $\frac{1}{X}$ = cold wash.

8 Programme selector dial

To select the required programme, turn this dial clockwise until the programme number is exactly opposite the pointer.

Before selecting a programme or changing a programme in progress the machine must be switched off by depressing ON/OFF button.

i Washing hints

Sorting the laundry

Follow the wash code symbols on each garment label and the manufacturer's washing instructions.

Sort the laundry as follows:

whites, coloureds, synthetics, delicates, woollens.

Temperatures

95° for normally soiled white cottons and

linen (e.g. tea cloths, towels, tablecloths,

sheets...)

for normally soiled, colour fast garments (e.g. shirts, night dresses, pyjamas....) in

linen, cotton or synthetic fibres and for

lightly soiled white cotton (e.g.

underwear)

★ (cold) for delicate items (e.g. net curtains),30°-40° mixed laundry including synthetic fibres

and woollens bearing the label «pure new wool, machine washable, non-

shrink».

Before loading the laundry

Never wash whites and coloureds together. Whites may lose their "whiteness" in the wash.

New coloured items may run in the first wash; they should therefore be washed separately the first time.

Make sure that no metal objects are left in the laundry (e.g. hair clips, safety pins, pins).

Button up pillowcases, close zip fasteners, hooks and poppers. Tie any belts or long tapes.

Remove persistent stains before washing. Rub particularly soiled areas with a special detergent or detergent paste.

Treat curtains with special care. Remove hooks or tie them up in a bag or net.

Maximum loads

Recommended loads are indicated in the programme charts.

General rules:

cotton, linen: drum full but not too tightly packed

synthetics: drum no more than half full

delicate fabrics and woollens: drum no more than one third full.

Washing a maximum load makes the most efficient use of water and energy.

For heavily soiled laundry, reduce the load size.

Laundry weights

The following weights are indicative:

bathrobe	1200 g
napkin	100 g
quilt cover	700 g
sheet	500 g
pillow case	200 g
tablecloth	250 g
towelling towel	200 g
tea cloth	100 g
night dress	200 g
ladies' briefs	100 g
man's work shirt	600 g
man's shirt	200 g
man's pyjamas	500 g
blouse	100 g
men's underpants	100 g

Removing stains

Stubborn stains may not be removed by just water and detergent. It is therefore advisable to treat them prior to washing.

Blood: treat fresh stains with cold water. For dried stains, soak overnight in water with a special detergent then rub in the soap and water.

Oil based paint: moisten with benzine stain remover, lay the garment on a soft cloth and dab the stain: treat several times.

Dried grease stains: moisten with turpentine, lay the garment on a soft surface and dab the stain with the fingertips and a cotton cloth.

Rust: oxalic acid dissolved in hot water or a rust removing product used cold. Be careful with rust stains which are not recent since the cellulose structure will already have been damaged and the fabric tends to hole.

Mould stains: treat with bleach, rinse well (whites and fast coloureds only).

Grass: soap lightly and treat with bleach (whites and fast coloureds only).

Ball point pen and glue: moisten with acetone (*), lay the garment on a soft cloth and dab the stain.

Lipstick: moisten with acetone as above, then treat stains with methylated spirits. Remove any residual marks from white fabrics with bleach.

Red wine: soak in water and detergent, rinse and treat with acetic or citric acid, then rinse. Treat any residual marks with bleach.

Ink: depending on the type of ink, moisten the fabric first with acetone (*), then with acetic acid; treat any residual marks on white fabrics with bleach and then rinse thoroughly.

Tar stains: first treat with stain remover, methylated spirits or benzine, then rub with detergent paste.

(*) do not use acetone on artificial silk

Detergents and additives

Good washing results also depend on the choice of detergent and use of the correct quantities to avoid waste and protect the environment. Although biodegradable, detergents contain substances which, in large quantities, can upset the delicate balance of nature.

The choice of detergent will depend on the type of fabric (delicates, woollens, cottons, etc.), the colour, washing temperature and degree of soiling.

All commonly available washing machine detergents may be used in this appliance:

- powder detergents for all types of fabric,
- powder detergents for delicate fabrics (60°C max) and woollens.
- liquid detergents, preferably for low temperature wash programmes (60°C max) for all types of fabric, or special for woollens only.

The detergent and any additives must be placed in the appropriate compartments of the dispenser drawer before starting the wash programme.

If using concentrated powder or liquid detergents, a programme **without** prewash must be selected.

Pour liquid detergent into the dispenser drawer compartment marked []] just before starting the programme.

Any fabric softener or starching additives must be poured into the compartment marked \& before starting the wash programme.

Follow the product manufacturer's recommendations on quantities to use.

Quantity of detergent to be used

The type and quantity of detergent will depend on the type of fabric, load size, degree of soiling and hardness of the water used.

Water hardness is classified in so-called "degrees" of hardness. Information on hardness of the water in your area can be obtained from the relevant water supply company, or from your local authority.

Follow the product manufacturers' instructions on quantities to use.

Use less detergent if:

- you are washing a small load
- the laundry is lightly soiled
- large amounts of foam form during washing.

Normal programmes for cottons and linens

Maximum load: 5 kg

Progr.	Temp.	Type of laundry	Cycle description	Possible options
1	60°-95°	Whites with prewash (heavy soiled)	Prewash Wash at 60°-95°C 3 rinses Long spin	16 1/2
2	60°-95°	Whites without prewash (normally soiled)	Wash at 60°-95°C 3 rinses Long spin	16 1/2
2	30°-60°	Coloureds (normally soiled)	Wash at 30°-60°C 3 rinses Long spin	16 1/2
3	60°	Quick wash lightly soiled laundry	Wash at 60°C 3 rinses Long spin	16 1/2
4		Rinses	4 rinses with fabric softener, if required Long spin	16 1/2
5		Softener	1 rinse with fabric softener, if required Long spin	†@
6		Spin	Drain and long spin	†@

The temperatures indicated are the optimum temperatures for each programme and depend on the type of laundry and degree of soiling.

Gentle programmes for synthetics, mixed fibres, delicates and woollens

Maximum load: 2 kg, woollens 1 kg

Progr.	Temp.	Type of laundry	Cycle description	Possible options
7	40°-60°	Synthetics with prewash (heavy soiled)	Prewash Wash at 40°-60°C 3 rinses Short spin	†@
8	40°-60°	Synthetics without prewash (normally soiled)	Wash at 40°-60°C 3 rinses Short spin	† @□
9	30°-40°	Delicate fabrics - Silk	Wash at 30°-40°C 3 rinses Short spin	† @□
10	40°	Woollens 🚳	Wash at 40°C 3 rinses Short spin	†@ ☐
11		Delicate rinses	3 rinses with fabric softener, if required Short spin	†@ □
12		Softener	1 rinse with fabric softener, if required Short spin	10□
13		Spin	Drain and short spin	10
14		Drain	Draining of water	

The temperatures indicated are the optimum temperatures for each programme and depend on the type of laundry and degree of soiling.

i Operating sequence

Before washing your first load of laundry, we recommend that you run a cotton cycle at 60°C, with the machine empty, in order to remove any manufacturing residue from the drum and tub. Pour half a measure of detergent into the main wash compartment and start up the machine.

1. Place the laundry in the drum


Open the door.

Place the laundry in the drum, one item at a time, shaking them out as much as possible. Close the door.




2. Measure out the detergent

Pull out the dispenser drawer until it stops. Measure out the amount of detergent recommended by the manufacturer in a graduated cup and pour it into the main wash compartment \coprod . If you wish to carry out a prewash, pour detergent into the appropriate compartment marked \coprod .




3. Measure out the additives

If required, pour fabric softener into the compartment marked & without exceeding the «MAX» mark.




4. Select the desired option(s)

Depress SPIN SPEED REDUCTION ↓ 6 and/or HALF LOAD (1/2) or ANTI-CREASE → button, if desired.




5. Select the temperature


Turn the selector dial to the required temperature setting.



6. Select the programme and start it

Turn the programme selector dial clockwise to the required wash programme and depress the ON/OFF button ①: the operating pilot light comes on and the machine starts to operate.





7. At the end of the programme

The machine stops automatically, the operating pilot light goes out.

If you have selected a programme which stops with water of the last rinse in the drum (anti-crease button depressed), drain the water before opening the door.

Drain the water by selecting programme **14** (drain) or release button \Box (the machine will drain and spin).

It is normal to have to wait for about 2 minutes before being able to open the door to allow the safety lock to release.

Depress the ON/OFF \bigcirc button again to switch the machine off.

Remove the laundry.

Turn the drum by hand to make sure it is completely empty, so as to avoid any forgotten items being damaged in a subsequent wash (e.g. shrinking) or their colour running into a load of whites.

Release any button which has been depressed.

Turn the water tap off and unplug the machine.

Leave the door ajar to air the machine.

i International wash code symbols

These symbols appear on fabric labels, in order to help you choose the best way to treat your laundry.

Energetic wash Delicate wash	Max. wash temperature 95°C	Max. wash temperature 60°C	Max. wash temperature 40°C	Max. wash temperature 30°C		rash Do not wash at all
Bleaching	Bleach in cold water			Do not ble	each	
Ironing	Hot iron max 200°C		Warm iron max 150°C	Lukewa max 1		Do not iron
Dry cleaning	Dry cleanin in all solven	nts pero	y cleaning in chlorethylene, l, pure alcohol, 111 & R 113	Dry cle in pe pure a and F	trol, Icohol	Do not dry clean
Drying	Flat	On the		Slothes nger	high temperature low temperature temperature	

Maintenance

1. Bodywork

Clean the outside of the machine with warm water and a neutral, non-abrasive household detergent. Rinse with clean water and dry with a soft cloth.


Important: do not use methylated spirits, solvents or similar products to clean the bodywork.

2. Detergent dispenser drawer


After a while, detergents and fabric softeners leave deposits in the drawer.

Clean the drawer from time to time by rinsing it under a running tap. To remove the drawer from the machine, press the button in the rear left-hand corner.

To facilitate cleaning, the top part of the additive compartments can be removed.



Detergent can also eventually accumulate inside the drawer recess: clean it with an old toothbrush. Refit the drawer after cleaning.



3. Water inlet filter

If you notice that the machine is taking longer to fill, check that the filter in the water inlet hose is not blocked.

Turn off the water tap.

Unscrew the hose from the tap.

Clean the filter with a stiff brush. Screw the hose back onto the tap.




4. Drain filter

The drain filter collects threads and small objects inadvertently left in the laundry. Check regularly that the filter is clean.

Open the filter door.

Place a container under the filter and unscrew it.



Pull out the filter.

Clean the filter under a running tap, then refit it, screwing it fully in.





5. Emergency emptying out

If the water is not discharged proceed as follows to empty out the machine:

- pull out the plug from the power socket;
- close the water tap;
- if necessary, wait until the water has cooled down;
- place a bowl on the floor;
- put the drain hose end into the bowl and let the water come out.


Something not working

Problems which you can resolve yourself

Problem	Possible cause
The machine does not start up:	Check that the door is firmly closed.
	 Check that the machine is plugged in and that there is power at the socket.
	Check that the main fuse has not blown.
	 Check that the programme selector dial is positioned correctly and the ON/OFF (1) button depressed.
The machine does not fill:	Check that the water tap is open.
	Check that water is coming out of the tap.
	 Check that the inlet hose is not squashed or kinked.
	Check that the filter in the inlet hose is not blocked.
	Check that the door is closed.
The machine fills then empties immediately:	The end of the drain hose is too low. Refer to relevant paragraph in "water drainage" section.
The machine does not empty and/or does	Check that the drain hose is not squashed or kinked.
not spin:	The ANTI-CREASE option has been selected.
	The drain filter is clogged. Clean it.
There is water on the floor:	Too much detergent or unsuitable detergent (creates too much foam) has been used.
	 Check whether there are any leaks from one of the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check to see if it is damp.
	Check that the drain hose is not damaged.
Unsatisfactory washing results:	Too little detergent or unsuitable detergent has been used.
	 Stubborn stains have not been treated prior to washing.
	The correct temperature or programme was not selected.

Problem	Possible cause		
The machine vibrates or is noisy:	 Check that all the transit bolts and packing have been removed. Check that the machine is not resting against anything. Check that the support feet are resting firmly on the ground. Check that the laundry is evenly distributed in the drum. Maybe there is very little laundry in the drum. 		
The door will not open:	 The programme is still running. The door lock has not yet been released. There is water in drum. 		
Water is not visible in the machine:	The machine, which is the result of modern technology, runs in a very economical way with low water consumption. Performance is nevertheless excellent.		
Spinning starts late or the machine does not spin:	The electronic unbalance detection device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after 6 minutes, the laundry is still not evenly distributed in the drum, the machine will not spin. In this case, redistribute the load manually and select the spin programme.		
The machine makes an unusual noise:	The machine is fitted with a commutator motor which makes an unusual noise compared with other traditional machines. This motor enables a softer start to the spin and controls the increase in spin speed better. In this way, machine performance is improved.		

If you are unable to identify or solve the problem, contact our service centre. Before telephoning, make a note of the model, serial number and purchase date of your machine: the Service Centre will require this information.



()	The Electrolux Group. The world's No. 1 choice.
	The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion is more than 150 countries around the world.